Commands

Extend partition size

> If the partition size was changed in Proxmox, then after the resize on the UI, restart the VM

1. 1. Get PV (Physical Volume) name (Ex: /dev/sda1)

   ```
   sudo pvs
   ```

   2. Resize the PV

   ```
   sudo pvresize /dev/sda1
   ```

   3. Get root logical volume name (Filesystem value of / row; for example: /dev/mapper/ubuntu--vg-root)

   ```
   df -h
   ```

   4. Expand logical volume

   ```
   sudo lvextend -r -l +100%FREE /dev/mapper/ubuntu--vg-root
   ```

Source:

- Can't resize a partition using resize2fs

Create sudo user

1. First create the user: `adduser **sammy**`
2. Add user to the *sudo* group: `usermod -aG sudo **sammy**`
3. Then either logout and log back in, or switch to the user: `su - **sammy**`

Source:

- How To Create A New Sudo Enabled User on Ubuntu 22.04

Replace text using sed

- ```
  sed -i 's/FIND_TEXT/REPLACE_TEXT/' file.txt
  ```
  ```

Revision #4
Created 2022-05-15 18:56:03 UTC by Tozo
Updated 2022-08-29 07:49:42 UTC by Tozo